

The logo for HydroMet, featuring a white diagonal slash followed by the text "HydroMet" in a bold, white, sans-serif font.

/ HydroMet

User Manual

HyQual - Water Quality Multi Probe

The KISTERS logo, consisting of a white stylized 'K' symbol followed by the word "KISTERS" in a bold, white, sans-serif font. Below the name is the tagline "Empowering decisions of tomorrow" in a smaller, white, sans-serif font.

KISTERS
Empowering decisions of tomorrow

Table of Contents

I	Disclaimer	4
II	Glossary + Abbreviations	5
III	Scope of Delivery	7
IV	Safety Instructions	8
V	Specific Safety Instructions	9
Part I	Introduction	10
Part II	Installation	11
2.1	Required Accessories	11
2.2	Protection for unattended logging	12
2.3	Operating Limits	12
Part III	Configuration	13
3.1	Snapshot, AutoSnap, and Logging	13
3.1.1	Using Snapshot and AutoSnap	13
3.1.2	Logging	13
3.2	Set Barometric Pressure	14
3.3	Set Time and Date	14
Part IV	Operation	15
4.1	Sensor Warm Up	15
4.2	Four Basic Deployment Methods	15
4.2.1	Manual Data Collection	15
4.2.2	Unattended Logging	15
4.2.3	Telemetry Relay	16
4.2.4	On-Line Monitoring	17
Part V	Maintenance	18
5.1	When to proceed to maintenance?	18
5.2	Keep your device clean	18
5.3	Calibration	19
5.3.1	Basics of Parameter Calibration	19
5.3.2	Sensor Response Factor (SRF)	20
5.3.3	Choosing Calibration Standards	20
5.3.4	Calibration Record (Cal Log)	22
5.3.5	Temperature	22
5.3.6	Dissolved Oxygen	22
5.3.7	Conductivity	23
5.3.8	pH	23
5.3.9	Reference Electrode	24
5.3.10	ORP	24
5.3.11	Depth and Vented Depth	25
5.3.12	Turbidity	25

Part VI	Troubleshooting	27
6.1	Use Status LED for Troubleshooting	27
6.2	Check active Components	27
6.2.1	Check if the Motherboard of the Sensor is OK	27
6.2.2	Check if any given sensor needs replacement	27
Part VII	Repair	28
Part VIII	Technical Data	29
Part IX	Obligations of the Operator and Disposal	30
9.1	Obligations of the Operator	30
9.2	Dismantling / Disposal	30
Part X	Appendices	32
10.1	Frequently Asked Questions	32
10.1.1	Visualization	32
10.1.2	Power supply	32
10.1.3	Data memory	34
10.1.4	Communication and connection	34
10.1.5	Software and user interface app	34
10.1.6	Warranty	35
10.1.7	Calibration and Maintenance	35
10.1.8	Integration	38
10.1.9	Deployment and Applications	38
10.1.10	Accessories	38
10.1.11	Measurement variables	38
10.1.12	Materials	40
10.1.13	Differences and common points - two versions HyQual 200 and HyQual 300T	40
10.1.14	Other topics	41

I Disclaimer

The information provided in this manual was deemed accurate as of the publication date. However, updates to this information may have occurred.

This manual does not include all of the details of design, production, or variation of the equipment nor does it cover every possible situation which may arise during installation, operation or maintenance. KISTERS shall not be liable for any incidental, indirect, special or consequential damages whatsoever arising out of or related to this documentation and the information contained in it, even if KISTERS has been advised of the possibility of such damages.

Any errors found in any KISTERS product should be reported to KISTERS where every effort will be made to quickly resolve the problem.

Copyright Notice: No parts of this work may be reproduced in any form or by any means without the written permission of the publisher. KISTERS waives copyright for users to print out parts of the documentation in hard copy for their own use only.

Trademark Notice: KISTERS products and services referred to in this document are trademarks or registered trademarks of KISTERS. Other product names used may or may not be the trademarks of their respective owners.

© 2024 | KISTERS. Any rights not expressly granted herein are reserved.

This document is public.

II Glossary + Abbreviations

Term	Description
AUTO SNAP	Refers to automatically capturing data, with the data stored in your display.
BP	Barometric Pressure
C	Conductivity
DO	Dissolved Oxygen
EBP	External battery pack HyQual 300T
Logging	Refers to unattended data capture, with the data stored in The HyQual probe.
Modbus	Modbus is a serial communication protocol. Method used for transmitting information over serial lines between electronic devices. There are two types of Modbus serial protocols, RS-232 and RS-485. Modbus RS-232 allows concurrent, full-duplex flow of data. Modbus RS-485 is half-duplex, and indicates values using differences in voltage. Modbus messages can also be sent over Ethernet or TCP/IP.
ODO	Optical Dissolved Oxygen
ORP	Oxidation-reduction potential
Redox	Reduction-oxidation, is a type of chemical reaction in which the oxidation states of substrate change.
RS-232	RS-232 is a serial communication which is more than able to perform for a short distance and low data speed requirements. RS-232 has a transmission speed of 1 Mb/s up to 15 M. Recommended Standard 232 is a standard originally introduced in 1960 for serial communication transmission of data.
RS-485	RS-485 is a serial interface, an industrial specification that defines the electrical interface and physical layer for point-to-point communication of electrical devices. The RS-485 standard allows for long cabling distances in electrically noisy environments and can support multiple devices on the same bus. RS-485 has a data transmission speed of up to 10Mb/s for a distance of 15 M. At the maximum of 1200 M, RS-485 transmits at 100 Kb/s.
RV	Raw voltage
SC	Specific Conductivity
SDI-12	Serial Digital Interface at 1200 baud, an asynchronous serial communications protocol for smart sensors, SDI-12 sensors reply to commands sent by the data logger, the standard also specifies supply voltage and current and includes modes for low-power operation.
SN	Serial number (the sensors have the SN of the probe)
SNAPSHOT	Refers to manually capturing one line of readings, with the data stored in your display.

Term	Description
SRF	Sensor response factor. Figure of merit for the calibration based on 100 as a reference value. It helps you know if calibration was properly done.
Telemetry Relay	It means that you have connected the HyQual probe to a telemetry device, deployed the HyQual probe in the proper location in the water, and left the site.
USB	Universal Serial Bus, an asynchronous serial communication protocol for peripheral devices

III Scope of Delivery

- 1 × either HyQual 200 or HyQual 300T multi-probe
- 1 × non-vented underwater cable (5, 10, 20, 30, 40 and 50 m)
- Temperature sensor, dissolved oxygen sensor, specific conductivity sensor, pH sensor and ORP sensor (all sensors are integrated in the selected multi-probe)
- 1 × weighted sensor guard
- 1 × kit: tool and maintenance
- 1 × internal memory
- 3-year warranty



Only for HyQual 300T:

- Turbidity sensor and its wiper
- Interface RS-232
- Soft carrying case
- ... and any option ordered with the multi-probe

IV Safety Instructions

- Read the user manual including all operating instructions prior to installing, connecting and powering up the KISTERS HyQual - Water Quality Multi Probe. The manual provides information on how to operate the product. The manual is intended to be used by qualified personnel, i.e. personnel that have been adequately trained, are sufficiently familiar with installation, mounting, wiring, powering up and operation of the product.
- Keep the user manual on hand for later reference!
- If you encounter problems understanding the information in the manual (or part thereof), please consult the manufacturer or its appointed reseller for further support.
- KISTERS HyQual - Water Quality Multi Probe is intended to be used in hydrometeorological or environmental monitoring applications.
- Before starting to work, you have to check the functioning and integrity of the system.
 - Check for visible defects on the HyQual - Water Quality Multi Probe, this may or may not include any or all of the following mounting facilities, connectors and connections, mechanical parts, internal or external communication devices, power supplies or power supply lines, etc.
 - If defects are found that jeopardize the operational safety, work must be stopped. This is true for defects found before starting to work as well as for defects found while working.
- Do not use the KISTERS HyQual - Water Quality Multi Probe in areas where there is a danger of explosion.
- The present user manual specifies environmental/climatic operating conditions as well as mechanical and electrical conditions. Installation, wiring, powering up and operating the KISTERS HyQual - Water Quality Multi Probe must strictly comply with these specifications.
- Perform maintenance only when tools or machinery are not in operation.
- If guards are removed to perform maintenance, replace them immediately after servicing.
- Never make any electrical or mechanical diagnostics, inspections or repairs under any circumstances. Return the product to the manufacturer's named repair centre. You can find information on how to return items for repair in the relevant section of the KISTERS website.



-  Disposal instructions: After taking the KISTERS HyQual - Water Quality Multi Probe out of service, it must be disposed of in compliance with local waste and environmental regulations. The KISTERS HyQual - Water Quality Multi Probe is never to be disposed in household waste!
-  Inputs and outputs of the device are protected against electric discharges and surges (so-called ESD). Do not touch any part of the electronic components! If you need to touch any part, please discharge yourself, i.e. by touching grounded metal parts.

V Specific Safety Instructions

- Handling of reagents needed for calibration purposes always requires special attention. Typically, the reagents used for calibration purposes of the multiprobe are considered non-hazardous. Ensure that Safety Data Sheets (SDS) are available for all chemicals used.
- In case of an incident: consult these documents, as they describe signs and symptoms of exposure, list first-aid procedures, and list spill cleanups.
- Secure all chemicals: store them out of reach of unauthorized personnel, ensure safety during transportation, and provide containers that will contain and resist the chemical in case of a spillage. Label all chemical containers clearly.
- Keep a handheld eyewash bottle in a chemical safety kit at hand and close to the location where the chemical reagents are used and stored.
- If possible, use small dropper bottles or sample bottles prefilled with a sufficient volume of preservative instead of transporting large containers of preservatives. Handling smaller volumes of chemicals lowers the risk and damage if a spill occurs.
- Do not pipette by mouth. Always use mechanical pipettes or pipette bulbs.

1 Introduction

Thank you for choosing our product. We hope you will enjoy using the device.

KISTERS manufactures, sells, installs and operates quality instrumentation, data loggers and communication technology. Products are designed with passion for environmental monitoring and with a deep understanding of the quality, accuracy and robustness needed to fulfil the requirements of measurement practitioners in the field.

The present User Manual will help you understand, install and deploy the device. If, however, you feel that a particular information is missing, incomplete or confusing, please do not hesitate to contact us for further support!




HyQual is a precision analytical measurement instrument. It integrates several sensors to determine a wide range of water quality parameters in a single housing. HyQual 200 and HyQual 300T are individual complete solutions and depending on the chosen model and optional extensions, the multi-probes can determine a subset or all of the following parameters:

- Temperature (standard)
- Dissolved oxygen (standard)
- Specific conductivity (standard)
- pH/ORP (standard)
- Total dissolved solids (standard)
- Salinity (standard) and turbidity (standard and only possible in HyQual 300T)
- Depth/level (optional) and barometric pressure (optional)

2 Installation

The probes should be installed in a place where there is a sufficient water flow, that can be easily accessed for maintenance and protected from external elements such as animals and items such as stones or sticks that may damage the probe.

This chapter contains the following subsections:

- [Required Accessories](#) 
- [Protection for unattended logging](#) 
- [Operating Limits](#) 

2.1 Required Accessories

Power supply

HyQual probes require a source of power.

Choices of power supply out of the water:

- For spot measurements, the optional external rechargeable Bluetooth® wireless technology battery enclosed in a waterproof (IP67) case connects to the probe via the HyQual probe's standard underwater cable running RS-232 or SDI-12. This battery operates only at the surface, and its job is to power the multiprobe while you're pairing the instrument with a data display via Bluetooth® wireless technology.
- A USB port on a PC is another way of supplying power to the multi-probes. For this case, you would need to add the optional USB adapter.
- HyQual also connects to third-party devices (data loggers, samplers, telemetry, etc.) that supply power.

Choices of power supply that operate underwater:

- Instead of using power from the underwater cable, you could use the optional EBP external re-chargeable battery pack. This battery is ideal for 300T due to its 75 mm (3 ") diameter. It also works fine with the 200 version, only it makes it look top-heavy. Use the EBP external battery pack when you do not wish to have downtimes of charging the battery. The EPB is removable, so you can replace it with a freshly charged battery right in the field.
Note: The use of EBP adds several millimeters to the length of the multiprobe.

Communication and connection

Available for the HyQual probes is an optional SDI-12 and ModBus interface, with either an SDI-12 or MODBUS adapter cable.

Connectivity and Visualization

When using a smartphone, tablet or other display device (Android™) you would need to add to your package the Bluetooth® wireless technology battery pack which allows connecting the external device with the probe via Bluetooth® wireless technology and additionally provides external power to the instrument.

HyQual also connects to a PC with the use of the optional USB Converter.

Vented capacity

With the vented depth sensor, the multiprobe automatically corrects depth measurements for changes in Barometric Pressure.

Note: Vented capacity is optional, it requires adding an optional depth sensor, optional vented depth capacity, and an optional vented cable.

Additionally, this capacity is incorporated in the probe, so you will add it when purchasing the probe. If you happen to have a probe and need to incorporate this capacity, you will have to send the probe back to us at your own expense.

Additional sensors

Barometric pressure is calculated with the use of the depth sensor therefore, you will need to add an optional depth sensor to any of your probes HyQual 200 and HyQual 300T.

When Absolute Pressure method is used (non-vented capacity) there are three ways of obtaining the value of Barometric Pressure:

- With the use of a theoretical Barometric Pressure
- With the use of the depth sensor, by taking the probe out of the water and placing it at the water surface so that the probe only measures the Barometric Pressure
- With a barometer (any brand)

Note: The barometric pressure value is needed for the calibration of the DO sensor.

2.2 Protection for unattended logging

There are 4 pipe kits available:

- Pipe kit 2" diameter: For protecting multiprobes, hinged locking cap
- Pipe kit 4" diameter: For protecting multiprobes, hinged locking cap



2.3 Operating Limits

- Input voltage: 5 V DC to 15 V DC
- Storage temperature: +1 °C to +50 °C
- Max. depth:
 - 50 m
 - 10 m for ISE or TDG

3 Configuration

This chapter contains the following subsections:

- [Snapshot, AutoSnap, and Logging](#) ¹³
- [Set Barometric Pressure](#) ¹⁴
- [Set Time and Date](#) ¹⁴

3.1 Snapshot, AutoSnap, and Logging

Logging refers to unattended data capture, with the data stored in The HyQual probe. The data are tagged with time and date. Logging is useful if the HyQual probe needs to collect data for days or weeks at a remote location.

Snapshot refers to manually capturing one line of readings, with the data stored in your Display. If you wish to log specific readings, tap the Snapshot button to save that data in your Display. The data will be tagged with time and date, and you can add an annotation if you wish.

AutoSnap refers to automatically capturing data, with the data stored in your Display. If you are running a short-term experiment or are monitoring a site for a few hours, AutoSnap will take a series of snapshots at the same interval as that you set for the interval between lines of rolling data.

3.1.1 Using Snapshot and AutoSnap

All the user interface versions have Hot Buttons for Snapshot and AutoSnap on the Home Screen. Simply press the button for the feature you wish.

You can change the file name you are using for Snapshots and AutoSnap (they are in the same file) any time you wish.

3.1.2 Logging

This chapter contains the following subsections:

- [Setting the Logging Interval](#) ¹³
- [Activate Logging](#) ¹⁴

3.1.2.1 Setting the Logging Interval

Go to the logging section of your user interface and follow the menu to set the logging interval.

3.1.2.2 Activate Logging

To initiate logging, you must tell the HyQual probe that you want it to start logging. All the user interface versions have a Hot Button for turning logging on, or off, on the Home Screen. Simply press the button to toggle between Logging ON and Logging OFF.

The Setup function for logging lets you name your logging file, and set the logging interval (time between logged lines of data).




Figure 1 - Switch Logging ON or OFF

Once logging is ON, supply the HyQual probe with power to start logging. For convenience, you may wish to take a Display to the field so that you can activate logging right before you place the HyQual probe in the water.

Note: Be aware that the blinking green LED communicates that you have adequate voltage to begin logging, and the blinking red LED (once you power up) that logging is properly enabled.

3.2 Set Barometric Pressure

The HyQual probe needs to have information about the local Barometric Pressure (BP) when calibrating DO. To calibrate BP, open the Calibration menu, select "Set BP", and type in the correct value (in mm Hg) in the first box on the screen. If you do not have information about the BP, you can set the approximate BP by typing your altitude (in feet) in the second box.

Note: If you type in BP, altitude is automatically calculated, and vice versa. The third method for setting BP is asking the HyQual probe the value (if the HyQual probe is equipped with a non-vented Depth sensor). If you choose this method, the correct values will automatically appear in the BP and altitude boxes.

3.3 Set Time and Date

To calibrate time and date, open the Calibration menu, select "Set Time and Date" to see the HyQual probe's current time and date. If you wish to change any of those values, just type the new value in the appropriate box or click the box at the bottom of the screen. If you wish to synchronize the HyQual probe time and date with that of your display, click the "synchronize" box.

4 Operation

This chapter contains the following subsections:

- [Sensor Warm Up](#) ^[15]
- [Four Basic Deployment Methods](#) ^[15]

4.1 Sensor Warm Up

The HyQual probe knows the warm-up times required for all the sensors you have enabled. It figures out exactly when to turn the various sensors on so that a frame of data can be taken exactly at the correct time. For instance, the DO sensor takes 20 seconds to warm up and the turbidity sensor takes 25 seconds to warm up. So, if you have only a DO sensor, the warm-up time will be 20 seconds. If you have DO and turbidity sensors, the warm-up time will be 25 seconds.

4.2 Four Basic Deployment Methods

There are four basic deployment methods for The HyQual probe.

This chapter contains the following subsections:

- [Manual Data Collection](#) ^[15]
- [Unattended Logging](#) ^[15]
- [Telemetry Relay](#) ^[16]
- [On-Line Monitoring](#) ^[17]

4.2.1 Manual Data Collection

Manual Collection is also known as profiling, surveying, spot measurement, site-to-site measurements, etc., means you are present at the monitoring site and using a Display for observing measurements. This allows you to make data-based decisions in the field in real-time at multiple monitoring sites in one day. The Display can be a laptop, or almost any tablet or smartphone. You can record measurements using the HyQual probe's Snapshot or Automatic Snapshot features. You might "snapshot" a series of measurements in one or more lakes or streams during the day, and then download your data to your desktop PC that evening. If your Display has email, you can email the data to anyone you wish, including yourself.

4.2.1.1 Uploading Snapshot and AutoSnap Data

If you are using a phone or tablet as your display, Snapshot and AutoSnap data are stored in your Display. If you wish to upload that data to a PC, simply follow the same procedure you would use to synchronize your PC and phone or tablet to transfer pictures, contact lists, etc. You can also email data files from your phone or tablet if they have Web access.

4.2.2 Unattended Logging

Unattended Logging means that you have set the HyQual probe into its logging mode, deployed the HyQual probe in the proper location in the water, and left the site. The HyQual probe can run for weeks at a time with cable-supplied power or an optional HyQual Internal Lithium Battery Pack. You can, for instance, set the instrument to take a set of readings every half-hour, anchor it in an estuary, and return after two weeks to retrieve the instrument and download the data to a PC, laptop, tablet, or phone.

4.2.2.1 Log Start on Power Up

HyQual starts logging when the user activates logging (see chapter [Activate Logging](#) ^[14]), and then provides power. When power is first provided, the red LED will blink five times to confirm that logging is activated, and the green LED will blink briefly to confirm that the HyQual probe is receiving adequate voltage to start logging.

4.2.2.2 HyQual Logging: Time Uniformity

For instance, if your logging interval is 15 minutes, and you turn logging on at five minutes past 10 AM, your first data will be logged at exactly 10:15, and then every 15 minutes thereafter. If your logging interval is one hour, and you turn logging on at five minutes past 10 AM, your first data will be logged exactly at exactly 11 AM, and then every hour thereafter. Your data is cleaner, and it's easier to match times if you wish to merge data sets.

4.2.2.3 Managing Log Files and Uploading Logging Data

Go to the Logging section of your user interface and follow the menu to name Logging files, change Logging files, erase Logging files, or upload Logging Data to a PC.

4.2.2.4 Powering the HyQual probe in Logging Mode

You can log data using an External Battery Pack (EBP) which is plugged to the probe or power from a secondary power source (such as a solar-recharged storage battery located above the water surface) via the Underwater Cable.

If you have an EBP and a secondary power source attached, the HyQual probe will use power coming from the secondary power source if its voltage is sufficient. If the HyQual probe cannot find adequate voltage in the Underwater Cable, it will use its EBP. This process preserves the HyQual probe batteries when possible. Other manufacturers, for reasons unknown, use the power source with the highest voltage, meaning that their batteries may be consumed quickly.

The HyQual 300T probes can be ordered with an optional External Battery Pack (EBP), a lithium rechargeable battery that you fix to the probe by plugging it, this means that you can purchase this battery after as it is not integrated to the probe.

Note: This battery adds several inches to the length of the probe and that it can also be used with the HyQual 200 only that its diameter would be larger than the HyQual 200's diameter which will make the probe look top-heavy, but it will work properly.

With an EBP, Logging starts when you use the Hot Button on the Home Screen to toggle from Logging OFF to Logging ON. The EBP is a rechargeable, "smart" Lithium battery that operates underwater, and it avoids downtime for charging the battery as you can replace it in the field with freshly recharged batteries without having to take the probe out of water. The EBP will power the HyQual probe for roughly 40 days, with a logging interval of 15 minutes in +25 °C water.

4.2.3 Telemetry Relay

Telemetry Relay means that you have connected the HyQual probe to a telemetry device, deployed the HyQual probe in the proper location in the water, and left the site. An Underwater Cable connects the HyQual probe to the telemetry system. The telemetry device uses satellite or cell-phone communication to periodically report HyQual data to your office PC or to a proprietary Web page. In many telemetry systems, you can also contact the HyQual probe and request transmission of the most recent data. Telemetry Relay lets you collect data all night and all day for weeks without being present at the monitoring site, and allows you remote access to collected data at any time. Telemetry is helpful in optimizing trips to the field for HyQual calibration or maintenance. Telemetry is also ideal in locations for which access is dangerous or expensive.

4.2.3.1 Logging Redundantly with Telemetry

If you wish to add redundancy to your data collection, you can connect a HyQual to a third-party data logger, telemetry device, etc. to store data in the HyQual probe (using its standard logging function) and in the third-party device (according to its manufacturer's instructions).

If you will be using an Underwater Cable, you can run power to the HyQual probe from a surface power supply to provide power to HyQual - you don't need a HyQual Battery Pack.

Or, the surface power supply can power HyQual with the optional internal lithium battery pack, thus saving your batteries for emergencies such as the failure of the surface power supply.

Either way, you will end up with data records in both the HyQual probe and the third-party device.

4.2.4 On-Line Monitoring

On-line monitoring, also known as process-control monitoring, means that the HyQual probe is connected to a PLC, SCADA system, etc. An example is monitoring the input to a water-treatment plant for salinity or chlorophyll. On-line monitoring allows you to make water-quality-based decisions in real-time. The HyQual probe is particularly effective in this application when more than one parameter is needed in the control loop or decision-making process.

5 Maintenance

This chapter contains the following subsections:

- [When to proceed to maintenance?](#) ¹⁸
- [Keep your device clean](#) ¹⁸
- [Calibration](#) ¹⁹

5.1 When to proceed to maintenance?

Judgement gained from observing your field conditions and data requirements provides information about when to maintain sensors. If you are logging data over long periods, the time when you collect your data from the HyQual probe is a good time for maintenance and calibration.

5.2 Keep your device clean

Clean your instrument periodically with warm soapy water; liquid dishwashing soap is fine. Do not use abrasives or strong solvents (such as acetone). Do not clean with gasoline, kerosene, or industrial cleaners. Mild household cleaners work well. You can clean sensor stems with a soft brush, but use only a rag or paper towel when cleaning the sensor's actual measurement surface.



Figure 2 - Rinsing a HyQual multiprobe

Rinse the HyQual probe well with tap water after cleaning, and store sensors with a few ounces of tap water in the Storage/Calibration Cup.

If you take the HyQual probe apart and expose O-rings, keep them and their mating surfaces greased with silicon grease (found in your maintenance kit). The same applies to your Underwater or Data Cable's lower connector. Replace any O-rings with visible cracks.



Figure 3 - Getting access to O-Rings

Always remove the batteries (if any) and clean the HyQual probe prior to storing it for prolonged periods. Always refill the reference electrode and recalibrate after long storage periods.

5.3 Calibration

This chapter contains the following subsections:

- [Basics of Parameter Calibration](#) ^[19]
- [Sensor Response Factor \(SRF\)](#) ^[20]
- [Choosing Calibration Standards](#) ^[20]
- [Calibration Record \(Cal Log\)](#) ^[22]
- [Temperature](#) ^[22]
- [Dissolved Oxygen](#) ^[22]
- [Conductivity](#) ^[23]
- [pH](#) ^[23]
- [Reference Electrode](#) ^[24]
- [ORP](#) ^[24]
- [Depth and Vented Depth](#) ^[25]
- [Turbidity](#) ^[25]

5.3.1 Basics of Parameter Calibration

The procedure for operating a HyQual, including making calibrations, varies with the type of display used because the user interface software can be different (mostly because of the differences in display screen sizes). You could also study the highly detailed appendices to familiarize yourself with the various procedures. Otherwise, you should be able to walk through the software once you have established communication between your display and the HyQual probe. You can become a minor expert in just a few minutes.

The HyQual probe never guesses parameter values, so you must calibrate it from time to time by simply telling the instrument what it should read in a calibration situation for which the correct parameter value is known. Here's the general procedure:

- Clean the sensor and perform any necessary sensor-specific maintenance.
- Select a calibration standard whose value is close to the values you expect to see in the field. For best results, use fresh calibration solutions and discard them once they have been used. But generally, you can reuse most calibration standards a few times if you are careful to avoid contamination.
- With the HyQual probe's Storage/Calibration Cup screwed onto the HyQual probe housing, rinse the sensors three times with a small quantity of your calibration standard by pouring the standard into the Storage/Calibration Cup, positioning the "stopper" side of the lid (the side with the O-ring) on top of the Storage/Calibration Cup, and shaking the HyQual probe vigorously to remove traces of old calibration solutions. Discard the used calibration standard between rinses.
- Next, secure the HyQual probe with the sensors pointing up and fill the calibration cup with your calibration standard. Make sure the standard covers the sensor entirely and that it also covers the thermistor for those parameters that are temperature-compensated. For turbidity sensors and other fluorometers, fill the cup to at least 1 ½ inches above the sensor's lens surface.

- Access your app's calibration function by navigating from the Home Screen to the calibration section. Select the parameter to be calibrated, and then enter the calibration value in the type-in box and press enter. When the reading has stabilized, press enter to calibrate. The HyQual probe will report the resulting Sensor Response Factor (SRF; see below). For most apps, you then press Y to accept the calibration, N to back up one step, or Exit to leave the sensor uncalibrated.

5.3.2 Sensor Response Factor (SRF)

Near the end of the calibration routine, you will be asked to accept or decline the calibration based on the Sensor Response Factor (SRF). Suppose that a "typical" conductivity sensor puts out 100 μA in a 1413 $\mu\text{S}/\text{cm}$ standard. If your conductivity sensor reports 100 μA in that same calibration solution, then your SRF is 100 % (some parameters, such as pH, have a more complex SRF calculation, but the effect is the same). If your response is 80 μA , your SRF would be 80 %. When you press the OK button to accept a calibration, the HyQual probe automatically accepts your calibration if the SRF is between 60 % and 140 %. If the SRF falls outside that range, you will be cautioned to check your standard value, make sure the sensor is clean, make sure the reading has stabilized, etc. But you can elect to accept any SRF.



5.3.3 Choosing Calibration Standards

For best results, choose a calibration standard whose value is close to what you expect to see in the field. For example, calibrate with a 1413 $\mu\text{S}/\text{cm}$ specific conductance standard if you expect to see specific conductance readings between 500 and 1000 $\mu\text{S}/\text{cm}$ in the field. Calibrating with a seawater standard or a very low standard would not be appropriate. Similarly, if your water tends toward the acidic side, calibrate with a 4-buffer instead of a 10-buffer.

If you are moving the HyQual probe across wide ranges of water conditions, you may wish to recalibrate to match the new situations. For instance, if you are measuring a clear lake during the morning and a high-sediment stream in the afternoon, you might consider recalibrating at noon with a high-value turbidity standard.


The table below shows common calibration practices.

Sensor	Standard Calibration	Method of	Available Solutions	Calibration	Comments
Temperature	never requires calibrating		N/A		
pH / pH reference	2 or 3 points		pH 4, pH 7, pH 10		pH 7, pH 10 most common
ORP	1 point		ORP Standard 200 mV		
Conductivity	1 point		CD Standard, 0.5 Molar, 58670 Micro S		brackish/saltwater
			CD Standard, 0.1 Molar, 12856 Micro S		borderline brackish typical
			CD Standard, 0.01 Molar, 1412 Micro S		fresh water, very pure
			CD Standard, 0.001 Molar, 147 Micro S		fresh/glacial
Reference Electrode	calibration not required		N/A		replace pH electrolyte solution at routine calibration
Depth	adjust for barometric pressure		N/A		recalibrate at deployment site for best accuracy
Turbidity	2 points		0 NTU, 10 NTU, 100 NTU, 400 NTU		calibrate near expected value
HDO (Optical DO)	calibrate at 100 % saturated water		DI water (shake vigorously to oxygenate)		set BP before calibrating; recalibrate at deployment site for best accuracy
Chlorophyll	2 points		secondary solid or 40 µg/l solution or lab sample		
Rhodamine	2 points		secondary solid standard or rhodamine		
Blue Green Algae	2 points		secondary solid standard or lab sample		
Ammonium (NH ₄ ⁺)	2 points		Lo 4.63 mg/l; Hi 46.3 mg/l		
Nitrate (NO ₃ ⁺)	2 points		Lo 4.62 mg/l; Hi 46.2 mg/l		
Chloride (CL ⁻)	2 points		CD Standard 147 Micro S		enter 34.3 mg/l for low calibration
			CD Standard 1412 Micro S		enter 319.3 mg/l for high calibration

Table 1 – Common Calibration Practices

5.3.4 Calibration Record (Cal Log)

Every HyQual probe has a dedicated data file called CAL.LOG. The CAL.LOG records every calibration made to your instrument, whether you accept the calibration or not. This file shows the time and date of the calibration, the parameter calibrated, the reading before the calibration was accepted, the reading after the calibration was accepted, the “raw” sensor reading, the SRF, and a few other details. If you wish to know, for instance, the last time that DO was calibrated, the calibration record would tell you when the most recent DO calibration was made, the value of the calibration standard, and the instrument’s reading in the standard before the calibration was made (to tell you exactly how much the instrument was changed during calibration). **Note:** This data cannot be altered within the HyQual probe.



Data	Time	Sensor	SN	Units	RV	Old	New	SRF
05/05/09	10:19:06	TURB	00000000	NTU	2.29472..	311.6	313.0	100
05/05/09	10:19:59	COND	05090159	µS/cm	2.70143..	1367	1412	111
05/05/09	10:20:42	PH	05090159	pH	-1.3684..	7.21	7.00	92
05/05/09	10:21:16	PH	05090159	pH	-1.7983..	10.13	10.00	100/92..
05/05/09	10:22:16	DO	05090159	%SAT	9.73200..	100.0	100.0	0

5.3.5 Temperature

The temperature sensor is an electrical resistor (thermistor) whose resistance changes predictably with temperature. The sensor is protected by a stainless-steel tube. Thermistors are very stable with time; they are factory-calibrated and do not require recalibration.

5.3.6 Dissolved Oxygen

The optical dissolved-oxygen sensor is a blue-light source, a sensing surface, and a red-light receiver. The sensing surface is an oxygen-active compound stabilized in an oxygen-permeable polymer, usually silicone. When the sensing surface is exposed to oxygen (in water or air), oxygen diffuses into the sensing surface according to the amount (partial pressure) of oxygen in the sample. The oxygen-active compound fluoresces by absorbing energy in the form of blue light and then emitting energy as red light. Oxygen “quenches” that fluorescence, so the more oxygen, the less fluorescence.

In each measurement cycle, the blue light is first turned on and then turned off. The red-light receiver measures the time it takes, after the blue light is turned off, for the fluorescence to die off. This value is proportional to dissolved oxygen.

DO readings are corrected for the water sample’s temperature and salinity (if you have a conductivity sensor).

KISTERS recommends the “air-saturated water” DO calibration method, as opposed to the “water-saturated air” calibration commonly used in the past. Here are the steps for air-saturated water calibration:

- Make sure your instrument’s barometric pressure setting is accurate. (C.14)
- Open the calibration menu and select “ADO %sat” for HyQual
- Put a half-liter of tap water in a liter jar, secure the lid, and shake the jar vigorously for one minute. Take the lid off the jar and let the water stand for about five minutes, so air bubbles float out.
- Screw your calibration cup onto the HyQual probe housing and remove the cup lid. With the sensors pointed upward, fill the calibration cup until the aerated water covers the DO sensor by a centimeter or so.
- Wait a few minutes for the temperature to equilibrate and the sensor to arrive at a steady reading.
- Now just follow the calibration instructions on the screen.

The manufacturers of optical-DO sensors usually recommend that you not calibrate the zero-DO point because the zero-DO point drift is very low. However, the HyQual probe supports zero-DO calibration, should you wish to check your sensor’s zero from time to time, using any of three methods:

- Dissolve a few grams of sodium sulfate and a pinch of cobalt chloride in a half-liter of tap water. You can buy this solution ready-to-use, but be careful not to aerate the solution by pouring it back and forth numerous times.
- If you do not wish to use the sodium sulfate method, you can prepare zero-oxygen water by bubbling nitrogen through water. Use bottled gas and an aquarium-type air stone. (If you’re using a high-pressure gas bottle, please use a two-stage regulator to prevent unnecessary excitement.) After bubbling the gas through, say, a liter of water for, say, 10 minutes, you should have a good zero.
- The simplest way to check for zero response is with nitrogen gas. Wrap the sensor end of the HyQual probe with a plastic bag and feed nitrogen gas into the bag. Make sure there’s another hole at the opposite end of the bag for the air to escape;

otherwise, you won't get a good zero, and the exploding bag will cause unnecessary excitement. (If you're using a high-pressure gas bottle, please use a two-stage regulator.)

Optical dissolved-oxygen sensor maintenance is little more than occasionally cleaning the sensing surface (the dark material, about a centimeter in diameter, at the tip of the sensor) with a cloth and soapy water.

Optical dissolved-oxygen sensors usually have very low drift rates. Practice will show you how often to calibrate DO, and you might find that one or the other of the calibration points (zero or 100 % saturation) does not require calibration every time you set the other point.

5.3.7 Conductivity

KISTERS uses the four-electrode method to determine water conductivity. Two pairs of graphite electrodes are situated in a stable geometry (you can barely see the electrodes; they look like two bull's eyes inside the slot on the conductivity sensor).

A constant voltage is applied to one of each electrode pair, and the amount of current required to maintain that voltage is measured. As the conductivity of the water increases, the current increases predictably.

Conductivity sensor maintenance is nothing more than occasionally cleaning the measurement surface with a soft cloth or cotton swab and soapy water. Do not use anything abrasive.

The zero point for the sensor is set electronically, so you need only set the "slope" point:

- Open the Calibration menu and select "SpCond $\mu\text{S}/\text{cm}$ " or "SpCond mS/cm ", depending on your preference of units.
- Screw your calibration cup onto the HyQual probe housing and remove the cup lid. Rinse your sensors several times with the standard you'll use for calibration.
- With the sensors pointed upward, fill the calibration cup until your solution covers the sensors by an inch or so.
- Wait a few minutes for the temperature to equilibrate and the sensor to arrive at a steady reading.
- Now just follow the calibration instructions on the screen.

The HyQual probe normally reports Specific Conductance – that's conductivity that has been standardized to 25 °C. Your reading is thus the conductivity of your water if that water was exactly 25 °C. Conductivity has three other forms, Total Dissolved Solids (TDS), Salinity, and Resistivity (which we don't report because it has little meaning in natural waters). You can't calibrate TDS or salinity directly because they are calculated from conductivity. You can, however, "calibrate" TDS with a TDS standard by adjusting the conductivity calibration point up or down until the TDS standard produces the desired TDS reading. The same is true for salinity if you're using a standard quantified on the Practical Salinity Scale (PSS). "Enable" TDS and/or salinity by checking the box next to those parameters in the "Sensors and Parameters" section.

5.3.8 pH

pH is measured as the voltage drop across the glass membrane of a pH electrode. A reference electrode is used to complete the voltage-measuring circuit. The pH glass is specially formulated to absorb water so that ions (particularly H^+ and OH^-) in the water are attracted to the glass to offset the ionic constituency of the pH electrode's internal electrolyte. As a result, there is a charge separation across the glass, and that's the voltage we measure. pH readings are automatically compensated for temperature.

pH electrode maintenance is nothing more than occasionally cleaning the glass surface with a soft cloth and soapy water. Do not use anything abrasive. The important part of pH maintenance is refilling the reference electrode. (D.10)

You can choose a two- or three-point pH calibration. The two-point calibration, a seven buffer and a second buffer whose value is near that of the waters you intend to monitor, is recommended. If you are measuring in waters whose pH might range significantly above and below seven, you may be able to increase your accuracy slightly by choosing a three-point calibration (seven buffers plus one basic buffer and one acidic buffer). pH calibration is simple:

1. Open the Calibration menu and select "pH".
2. Screw your calibration cup onto the HyQual probe housing and remove the cup lid. Rinse your sensors several times with the standard you'll use for calibration.
3. With the sensors pointed upward, fill the calibration cup until your solution covers the sensors by an inch or so.
4. Wait a few minutes for the temperature to equilibrate and the sensor to arrive at a steady reading.
5. Now just follow the calibration instructions on the screen.
6. Repeat steps 2 – 5, as directed by the software, if you wish to calibrate at a second or third pH value.

5.3.9 Reference Electrode

The key to reliable pH, ORP, and ISE measurements is a well-maintained reference electrode. Recall that a reference electrode is required to complete voltage measurement for pH readings.

Reference electrode maintenance is simple:

- Remove the reference cap by unscrewing it from the reference sleeve and discard old reference electrolyte.
- Fill the sleeve completely with fresh pH reference electrolyte (KCl saturated with silver chloride). Tap the HyQual probe a few times to dislodge any bubbles.
- Screw the reference cap back on to the sleeve. As you screw the sleeve into place, air and excess electrolyte is forced out of the sleeve through the reference electrode junction (the white, porous circle at the end of the sleeve). This not only purges bubbles from the electrolyte, but also cleans nasty stuff out of the junction.



Figure 4 - Filling in fresh pH reference electrolyte

5.3.10 ORP

ORP is also known as Oxidation-Reduction Potential or Redox. The actual ORP sensor is the 1 mm platinum dot you can see when looking down at the pH sensor - if the HyQual probe has ORP. Because platinum does not react with ions in the water, it won't give or take any electrons from those ions unless they are very persuasive. The potential (voltage) created by this refusal is what you're actually measuring as ORP. As it is with pH measurement, the reference electrode completes the voltage-measuring circuit.

ORP electrode maintenance is nothing more than occasionally cleaning the platinum surface with a soft swab and soapy water. If the platinum is discolored, you can polish the ORP electrode with a very light abrasive, like 900-grit wet-and-dry sandpaper (please be careful not to polish the pH glass bulb). The most important part of ORP maintenance is refilling the reference electrode. (D.9)

ORP uses a one-point calibration:

- Open the calibration menu and select "ORP".
- Screw your calibration cup onto the HyQual probe housing and remove the cup lid. Rinse your sensors several times with the standard you'll use for calibration.
- With the sensors pointed upward, fill the calibration cup until your solution covers the sensors by an inch or so.
- Wait a few minutes for the temperature to equilibrate and the sensor to arrive at a steady reading.
- Follow the calibration instructions on the screen.

5.3.11 Depth and Vented Depth

Depth is measured by a strain-gauge transducer as hydrostatic water pressure. The deeper you go in the water, the higher the pressure.

KISTERS' depth sensors are usually buried inside the instrument, with a small pressure port that can be seen on the outside of the HyQual probe bottom cap. They require no regular maintenance, but you might check occasionally to make sure the pressure port is not clogged. If it is, use something soft, like a toothpick, to clear the port of obstruction.

Depth calibration is nothing more than “zeroing” the sensor in air, where one assumes the water depth to be zero:

- Make sure the HyQual probe is not in the water.
- Open the Calibration menu and select “Depth”.
- Now just follow the calibration instructions on the screen.

Note: The Depth sensor cannot distinguish between water pressure and the air pressure over that water (i.e., barometric pressure). After you have zeroed the sensor, any change in barometric pressure will be measured as a change in water pressure.

Another choice is using Vented Depth (Stage). Vented Depth uses the same transducer as does Depth, except that there's a small hole in the back of the transducer. There is a tube inside the cable (i.e., a Vented Cable) to connect the Stage sensor to the atmosphere so that changes in barometric pressure will not affect the Depth reading.

Vented-Depth cables have a desiccant-filled housing at their surface end. The desiccant keeps water from condensing in the vent tube by letting vapor escape through a small Gore-tex patch. Keep that housing clean and replace the desiccants every year.

5.3.12 Turbidity

Turbidity is measured as the fraction of an infra-red light beam that is scattered at 90° to that beam. More particles in the water mean more of that light is scattered, so the turbidity reading is higher.

Any material that accumulates on the optical surfaces of the Turbidity sensor is indistinguishable from material in the water, so most Turbidity sensors have little wipers to clean the window(s).

Turbidity sensors require no regular maintenance, but you might check occasionally to make sure the optical window (i.e., the little glass port on the front of the sensor) has not been damaged by overzealous wiping.

Turbidity uses a two-point calibration; one point is zero turbidity, and the other point should be a standard approximating the turbidity of the water you intend to monitor.



Make sure you use enough calibration standard to cover the sensor's “optical volume” – imagine a golf ball stuck on the end of the sensor; make sure there are no objects in the volume represented by that ball. One common method is keeping calibration solutions in one-liter, dark, wide-neck bottles with a non-reflective finish (such as Nalgene 2106 bottles in amber).

For the zero calibration:

1. Open the Calibration menu and select “Turb NTU” or “Turb FNU” depending on your preference for measurement units.
2. Screw your calibration cup onto the HyQual probe housing and remove the cup lid. Rinse your sensors several times with the standard you'll use for calibration.
3. With the sensors pointed upward, fill the calibration cup until your solution covers the sensors by at least an inch or so.
4. Wait a few minutes for the temperature to equilibrate and the sensor to arrive at a steady reading.
5. Follow the calibration instructions on the screen.

If you wish to calibrate at a second point, repeat steps 2 – 5 with a different turbidity standard.

A clean wiper means better measurements. If the wiper pad has deteriorated or is clogged with debris from your water (algae, silt, etc.), you should change it. For best results, you might consider changing the wiper pad prior to each long-term deployment. To change the wiper pad:



- Make sure you have the 1.5 mm hex key and a new pad for the wiper. Loosen the small set screw on the wiper arm.
- Remove the wiper pad from the wiper arm and replace the pad.
- Place a new wiper arm on the motor shaft so that the set screw faces the flat spot on the motor shaft.
- Gently press the wiper pad against the face of the probe until the pad is compressed to roughly three-quarters of its original thickness. It is important that the wiper arm does not contact the probe face - only the pad should be in contact. A gap of 0.5 mm between the wiper arm and the probe face is typical when a new pad has been installed. Another way of setting the pad gap is to place the pad so that you can slide a small piece of paper under the pad, but snug enough that the pad will hold the paper.
- Tighten the set screw.

Note: Do not over-tighten the set screw on the little rotating arm that holds the wiper pad, as that will strip the threads. Do not rotate the wiper arm manually either, as that will strip the gears.

6 Troubleshooting

We designed the HyQual probes so you do not be a specialized technician troubleshooting if something goes wrong.

For more information, see the following subsections:

- [Use Status LED for Troubleshooting](#)^[27]
- [Check active Components](#)^[27]

6.1 Use Status LED for Troubleshooting

Any HyQual probe has three light-emitting diodes (LEDs) mounted on the circuit board and visible through the instrument housing to help you understand what the HyQual probe is doing or not doing and to provide information when troubleshooting.

The green light blinks every second when the HyQual probe is receiving adequate operating voltage via the cable; it does not blink when the HyQual probe operates under its own battery power.

The amber light blinks when the HyQual probe is receiving RS-232 communications from an external device (such as a PC or logger).

When you first power up the HyQual probe, a sequence of red and amber light flashes provides information about the voltage of the External Battery Pack (if any) and whether logging is activated or not. The red light will blink five times to indicate that logging is activated and to indicate the first 3.5 volts of battery power. Then the amber light will blink once for each volt over 3.5 volts, and then the red light may blink for an additional half-volt.

For instance, five red blinks, five amber blinks, and a red blink mean logging is enabled and the External Battery Pack is putting out $3.5 + 5 + 0.5 = 9$ volts.

6.2 Check active Components

This chapter contains the following subsections:

- [Check if the Motherboard of the Sensor is OK](#)^[27]
- [Check if any given sensor needs replacement](#)^[27]

6.2.1 Check if the Motherboard of the Sensor is OK

If the HyQual probe turns on and reads any of its parameters correctly, then the basic communication circuitry is OK; if not, a new CPU board is needed.

6.2.2 Check if any given sensor needs replacement

If the HyQual probe reads temperature, but not, for example, conductivity, then a new conductivity sensor is needed. Contact KISTERS, we will send you the replacement component by your local courier service. You can install it on your own in a few minutes. There's no labor charge. 1 - 2 days of downtime.

7 Repair

KISTERS precision instruments and data loggers are produced in quality-controlled processes. All KISTERS production and assembly sites in Australia, New Zealand and Europe are ISO 90001 certified. All equipment is factory tested and/or factory calibrated before it is shipped to the client. This ensures that KISTERS products perform to their fullest capacity when delivered.

Despite KISTERS most rigorous quality assurance (QA), malfunction may occur within or outside of the warranty period. In rare cases, a product may not be delivered in accordance with your order.

In such cases KISTERS' return and repair policy applies. For you as a customer, this means the following:

- Contact KISTERS using the Repair Request Form and the Declaration of Contamination made available online:

Region (Language)	Download Link
Asia-Pacific (English)	Repair Request Form (APAC) Declaration of Contamination (APAC)
Europe, the Middle East and Africa (English)	Repair Request Form (EMEA) Declaration of Contamination (EMEA)
Germany (German)	Repair Request Form (DE) Declaration of Contamination (DE)

In response you will receive a reference number that must be referenced on all further correspondence and on the freight documents accompanying your return shipment.

- Please provide as much information and/or clear instructions within the return paperwork. This will assist our test engineers with their diagnosis.
- Please do not ship the goods prior to obtaining the reference number. KISTERS will not reject any equipment that arrives without reference number; however, it may take us longer to process.

Custom requirements for items sent to KISTERS for warranty or non-warranty repairs: Check with your national customs/tax authorities for details, processes and paperwork regarding tax exempt return of products. Typically, special custom tariff codes are available (such as HS Code = 9802.00) that verify the item is being returned for repair and has no commercial value. Please note that the customs invoice / dispatch documents should also clearly state: "Goods being returned to manufacturer for repair - No Commercial value". It is mandatory to have any returned goods accompanied by a commercial invoice on headed paper. KISTERS reserves the right to charge the customer for time spent rectifying incorrect customs documents.

Note: Please ensure that your goods are packed carefully and securely. Damage that occurs during transit is not covered by our warranty and may be chargeable.

8 Technical Data

	HyQual 200	HyQual 300T
Diameter	50 mm (1.95")	75 mm (2.95")
Length	47.8 cm (18.8")	47.8 cm (18.8")
Mass	0.82 kg (1.8 lbs.)	1.63 kg (3.6 lbs.)
Standard	Temperature sensor, dissolved oxygen sensor, specific conductivity sensor, pH sensor and ORP sensor, calculated total dissolved solids, calculated salinity, interface RS-232, weighted sensor guard, internal memory (months of datalogging), maintenance kit, carrying case, non-vented underwater cable (5, 10, 20, 30, 40 and 50 m)	
		Turbidity sensor, wiper
Options	Depth (level) sensor, barometric pressure, vented capacity, data cable for display devices (not for field use), calibration solutions, copper anti-fouling kit, USB adapter (connect DB9 to USB), integrated SDI-12 and MODBUS output, SDI-12 adapter cable, MOD-BUS adapter cable and Android display	
Material	Resistant materials like stainless steel 303 and 316, polyacetal (Delrin), PVC, Teflon, ABS, titanium, Viton, neoprene, silicone, glass	
Power Supply and Consumption	<ul style="list-style-type: none"> ▪ Supply: Underwater cable (incl.), or Bluetooth® wireless technology battery pack (opt.), or External battery pack (opt.) ▪ Consumption: Depends on the number of sensors, logging interval and site conditions. Battery dimensioned to ensure long autonomy. ▪ Rechargeable external lithium battery choices (optional): <ul style="list-style-type: none"> ▪ Spot measurement: Bluetooth battery pack that operates at the surface. ▪ Continuous logging: Battery that operates underwater, with the same diameter as HyQual 300T but it fits HyQual 200. 	
Output (Interfaces) Options	Standard: RS-232. Optional: Bluetooth® wireless technology, SDI-12, MODBUS)	
Certifications	CE, RoHS (WEEE pending)	

9 Obligations of the Operator and Disposal

This chapter contains the following subsections:

- [Obligations of the Operator](#) ³⁰
- [Dismantling / Disposal](#) ³⁰

9.1 Obligations of the Operator

European Union

In the Single European Market it is the responsibility of the operator to ensure that the following legal regulations are observed and complied with: national implementation of the framework directive (89/391/EEC) and the associated individual directives, in particular 2009/104/EC, on minimum safety and health requirements for the use of work equipment by employees at work.

Worldwide

Regulations: If and where required, operating licences must be obtained by the operator. In addition, national or regional environmental protection requirements must be complied with, regardless of local legal provisions regarding the following topics:

- Occupational safety
- Product disposal

Connections: Local regulations for electrical installation and connections must be observed.

9.2 Dismantling / Disposal

When disposing of the units and their accessories, the applicable local regulations regarding environment, disposal and occupational safety must be observed.

Before dismantling

- Electrical Devices:
 - Switch off the units.
 - Disconnect electrical appliances from the power supply, regardless of whether the appliances are connected to the mains or to another power source.
- Mechanical devices:
 - Fix all loose components. Prevent the device from moving independently or unintentionally.
 - Loosen mechanical fastenings: Please note that appliances can be heavy and that loosening the fastenings may cause them to become mechanically unstable.

Disposal

Operators of old appliances must recycle them separately from unsorted municipal waste. This applies in particular to electrical waste and old electronic equipment.

Electrical waste and electronic equipment must not be disposed of as household waste!

Instead, these old appliances must be collected separately and disposed of via the local collection and return systems.

Integrated or provided batteries and accumulators must be separated from the appliances and disposed of at the designated


collection point. At the end of its service life, the lithium-ion battery must be disposed of according to legal provisions.

EU WEEE Directive

As players in the environmental market, KISTERS AG is committed to supporting efforts to avoid and recycle waste. Please consider:

- Avoidance before recycling!
- Recycling before disposal!



This symbol  indicates that the scrapping of the unit must be carried out in accordance with Directive 2012/19/EU. Please observe the local implementation of the directive and any accompanying or supplementary laws and regulations.

10 Appendices

10.1 Frequently Asked Questions

This chapter contains the following subsections:

- [Visualization](#) ³²
- [Power supply](#) ³²
- [Data memory](#) ³⁴
- [Communication and connection](#) ³⁴
- [Software and user interface app](#) ³⁴
- [Warranty](#) ³⁵
- [Calibration and Maintenance](#) ³⁵
- [Integration](#) ³⁸
- [Deployment and Applications](#) ³⁸
- [Accessories](#) ³⁸
- [Measurement variables](#) ³⁸
- [Materials](#) ⁴⁰
- [Differences and common points - versions HyQual 200, and HyQual 300T](#) ⁴⁰
- [Other topics](#) ⁴¹

10.1.1 Visualization

Is external display available? If yes, what type of cable do I need? Can I use wireless technology such as Bluetooth®?

Yes; Android displays are available at an extra cost, as well as the optional data cable that connects the probe to the display device (not for field use) and the optional Bluetooth® wireless technology battery pack, which works as a transceiver to connect to the external display. HyQual uses Bluetooth® wireless technology because the ports on mobile phones and tablets are not standardized for a proper cable.

10.1.2 Power supply

Which standard power supply comes with the units?

What is standard and what is optional? Various options are available and designed to meet specific requirements of the type of deployment of the HyQual sensor.

All HyQual models have an optional EBP External Battery Pack for a self-contained data logger for both continuous logging and spot measurements. This rechargeable battery is ideal for HyQual 300 and HyQual 300T due to its 75 mm (3 ") diameter. It also works with the HyQual 200; it will look top heavy but it works well. The EPB is removable so you can replace it with a freshly charged battery right in the field.

Note: The use of EBP adds several millimeters to the length of the multiprobe.

If your power source is from the surface, and you are doing spot measurements, you can use any 6 V to 15 V power including the optional Bluetooth® wireless technology Battery Pack enclosed in a waterproof (IP67) case, which connects to the probe via the standard underwater cable running RS-232 or SDI-12. This battery operates only at the surface; its job is to power the multiprobe while you're pairing the instrument with a data display via Bluetooth® wireless technology.

HyQual connects to third-party devices (data loggers, samplers, telemetry, etc.) that supply power.

The use of USB port on a PC / laptop is another way of supplying power to the probes. For this purpose, it is necessary to have an optional USB adapter.

Would both battery types - Bluetooth and external (no Bluetooth) - last the same?

Yes.

How long does the battery last?

40 days with a logging interval of 15 minutes in 25 °C water.

However, the battery consumption depends on the logging interval and site conditions as a general rule. All our choices of battery use the same type of battery. It gives eight hours of continuous operation but, when logging, in particular, the logging interval is an important factor.

Estimation of battery life for four different cases:

- Case 1 Standard HyQual 200 (4 sensors) temp, SC, DO, and pH /ORP sensors:
With a 30-minute logging interval in room-temperature water, about 100 days of service.
- Case 2 Standard HyQual 300T (5 sensors) temp, SC, DO, pH /ORP and turbidity sensors:
With a 30-minute logging interval in room-temperature water, about 70 days of service.
- Case 3 HyQual 200 with additional depth sensor (5 sensors) temp, SC, DO, pH /ORP and depth sensors:
Depth and pH draw essentially zero power, so the service would be with a 30-minute logging interval in room-temperature water, about 100 days of service.
- Case 4 HyQual 300T (6 sensors) temp, SC, DO, pH /ORP, turbidity and depth sensors:
Depth and pH draw essentially zero power, so the service would with a 30-minute logging interval in room-temperature water, about 70 days of service.

Is the Bluetooth® wireless technology battery pack external or internal/inside the probe?

The Bluetooth® wireless technology Battery Pack is external. Bluetooth® wireless technology is not very useful underwater.

When do I use the external battery pack EBP and when the Bluetooth® battery pack? Are there cases when I use both?

The Bluetooth® wireless technology battery pack is external as well as the EBP.

They both use the same type of battery: lithium. The two battery types work for the three versions however, the EBP is meant to be used with 300T due to its diameter of 75 mm (3") - but it can fit the HyQual 200. The 200 version with EBP will look top heavy, but it will work properly. The Bluetooth® battery pack works well with all probes.

The external battery pack is meant be used for unattended monitoring, when continuous logging applies for an extended length of time and when the instrument power is not supplied from a source at the surface. The Bluetooth® Battery Pack only operates at the surface; its main purpose is to power the multiprobe while you're pairing it with a data display.

On the other hand, use the external battery pack when you do not wish to have downtime when you are charging the battery, as it is removable, you can replace it with a freshly charged battery when you do field work and visit the site.

Note: The use of EBP adds several millimeters to the length of the multiprobe.

What battery pack do I need for unattended monitoring? Are both battery choices Bluetooth® and External battery (no Bluetooth) suitable?

Use the external battery pack (EBP) for HyQual 200 or 300T for unattended monitoring, this battery operates underwater, powering the multiprobe while it is logging automatically.

From reading the manual, I understand that when you connect the probe to an external power source, the probe prioritizes external power over battery for maximum battery life. Is this correct?

Yes.

If you use the external Bluetooth® battery power and the external battery pack (EBP), would the probe first use the Bluetooth battery and then the external battery that is plugged into the probe?

Yes.

For my battery pack, when looking in the log file at battery voltage, at what point will the probe stop logging?

The voltage provided by an external battery pack (EBP) is shown as cable voltage. There is no fixed cutoff point, but any time the battery pack or cable voltage drops below about 5 V DC, the voltage may not be adequate for the HyQual probe to boot properly.

10.1.3 Data memory

How many logged readings does the probe have?

All KISTERS multiprobes have memory for logging, but they need a power source. This standard internal memory allows for months of data logging. You cannot estimate the number of values you can log because different data strings require different amounts of memory. HyQual can log much more data than you would want to analyze - many months' worth of data before you would need to clear out the memory.

10.1.4 Communication and connection

What interfaces uses HyQual?

RS-232 as standard output choice. SDI-12, MODBUS and Bluetooth® wireless technology are optional.

Note: For these optional outputs, you also need to add optional SDI-12 and MODBUS cables accordingly and for the Bluetooth interface you need the optional Bluetooth battery pack.

How does HyQual connects/communicate?

HyQual probes speak RS-232 protocol as their native language, but we provide converters for SDI-12 and MODBUS if you prefer.

The standard underwater cable running RS-232 or SDI-12/MODBUS connects the instrument to an optional Bluetooth® wireless technology Battery Pack to connect via Bluetooth® wireless technology to almost any smartphone, tablet, third-party devices.

The optional USB converter connects the probe to a PC / laptop via the underwater cable.

Additionally, the probes can be connected via the same underwater cable to an external control system, external data logger, etc.

Note: The SDI-12+ Modbus output require that the probes are equipped with the SDI-12/MODBUS interface module.

How do I transfer or export data from the probe via the underwater cable?Is it Bluetooth® wireless technology possible?

Yes, in general, most people who are doing spot measurements use the Bluetooth® battery pack when they are in the field to connect via the underwater cable to a data display device such a Tablet and with the use of the user interface app manage the data. Other persons often use a PC / laptop when in the lab / office.

In case I do not have Bluetooth®, what port do I need on my laptop and what software?

You can connect a HyQual probe to a PC / laptop with our optional USB adapter. The USB port will power the instrument. HyQual Control software is needed.

What is the range of the Bluetooth®?

The range is hard to estimate due to differences in Bluetooth® wireless technology over the years. You can estimate your Bluetooth® range by connecting the HyQual probe to the Bluetooth® Battery Pack, pairing it with a Data Display like an android device and gradually walking with the Data Display until the connection breaks. You should get a connection of at least 100 ft (30.5 m).

How much time does the Bluetooth® Battery need to fully charge?

We recommend charging it overnight, but you can get a partial charge in an hour or two.

10.1.5 Software and user interface app

About the Geofencing feature on the app, how is the GPS metadata stored? How can I access it for my archive and cross-check it?

The GPS data is stored on the specific tablet, separate from the probe data. First, within your tablet's settings, turn on Location Services. You'll have to export the GPS metadata as your tablet and its operating system permit.

Can I change the date format in the software?

You cannot. The format is mm/dd/yy. However, you may download the data and then change it in an Excel sheet if you need or prefer.

Does the software have a COM port limit? Is there a maximum number of devices to which I can connect? Can I connect to probes by other brands?

Our COM ports are unlimited.

What COM port should I use?

You should have little concern about choosing a communication port (COM port); the PC / laptop will identify it. Please see the user manual on the [HyQual webpage](#), and the topic "Choosing Calibration Standards".

Is the highlighted / colored top line an average of the values or the latest reading?

Data in the highlighted / colored band is the most recent data obtained from the HyQual probe.

10.1.6 Warranty**What is the life expectancy of the sensors?**

A three-year warranty is offered on the sensors, which typically last at least five years.

What does the 3-year warranty of HyQual probes cover?

It covers the probe, all the sensors and some accessories.

10.1.7 Calibration and Maintenance**Is barometric pressure needed for the calibration of the dissolved oxygen (DO) sensor?**

Yes.

How do you set the barometric pressure for calibration?

To set the Barometric pressure, use the HyQual Control software or User Interface App. You either need to have a barometer (don't use the weather station's BP value because it's corrected to sea level) or if you do not have a barometer, enter your elevation and barometric pressure will be estimated. If you have a depth sensor, click the "Get BP" button and it will ask the depth sensor for the barometric pressure value.

For more information, see [Measurement variables](#) .

Note: Make sure the probe is not under water, so it is looking at air pressure - not water pressure.

How often do HyQual probes need to be calibrated?

That depends on a number of factors, including the nature of the waters being monitored and your expectations for accuracy. We suggest that you start by calibrating once per week and shorten or lengthen that interval as the data suggest.

How do I know when I need to maintain the sensors?

Insight gained from observing your field conditions and data requirements suggest when you must maintain sensors. If you are (continuously) logging data over long periods (unattended), the time you go into the field to collect data from the HyQual is a good time for maintenance and calibration.

What is the range of millivolts (mV) for each pH solution?

With the HyQual, you do not need to worry about mV and frequent replacement of the pH / reference electrode like other multiprobes require. With the HyQual probe, just refill your reference electrode every two months or so and forget about mVs.

How do you clean the sensors?

A soft brush, water and soap are all you need to clean the sensors. If you need more than that, you could use more aggressive chemicals but be careful with the top of the sensors where the measurement faces are located

How do I know when I need to calibrate my sensors?

Considering that a frequent calibration ensures better data, the more meticulous you are with calibration, the better data you will get. If you are uncertain whether you need to calibrate, check your sensors against a known sample. If the reading is within the accuracy specification and/or your accuracy expectations, there is no need to calibrate.

Experience and your program's accuracy expectations will help determine calibration frequency for the various sensors. For instance, if your reservoir discharge is hovering near the regulatory minimum for dissolved oxygen (DO), pay special attention to DO calibration frequency and technique. On the other hand, if a conductivity accuracy of $\pm 10\%$ is OK, you will not need to calibrate conductivity very often.

How often do I need to replace the reference electrode of the pH/ORP sensor?

HyQual probes allow you to refill the reference electrode of the pH/ORP sensors. Refill the reference electrode by unscrewing the cap, putting in more electrolyte, and screwing the cap back on.

How often should I change the pH electrolyte?

Electrolyte usually lasts two months or more. But if you are logging data, or monitoring in water with very low conductivity, change your electrolyte each time before you recalibrate pH if possible. You may learn a better rule of thumb as you review your data. Overall, we recommend that you change your electrolyte every month. Changing electrolyte takes only a minute and it is basically free.

How long will my dissolved oxygen (DO) cap last?

With a HyQual probe, expect your DO caps to last five years or more. You can see the condition of your cap when you calibrate the DO sensor.

How often should I change my turbidity wipers?

Wipers usually last for years, but you should change them if they get stiff or you notice nicks in them.

Can I replace the sensors myself, or do I have to ship the HyQual probe to KISTERS?

KISTERS sensors seldom need replacement; hence, the three-year warranty is offered, not a one-year warranty for other probes and sensors. If you have a problem, HyQual sensors are easy to replace. Contact [KISTERS Customer Service](#) for assistance.

How Do I Choose Calibration Standards?

For best results, choose a calibration standard with a value close to what you expect to see in the field. For example, calibrate with a 1413 μS Specific Conductance standard if you expect to see Specific Conductance between 500 and 1000 μS in the field. Don't calibrate with a sea water standard. If your waters tend to be acidic, calibrate with a 4-buffer instead of a 10-buffer.

If you are moving the same HyQual probe across wide ranges of water conditions, you may wish to recalibrate it to match the new situation. For instance, if you are measuring a clear lake during the morning and a high-sediment stream in the afternoon, consider recalibrating at noon with a high-range turbidity standard.

What is the meaning of SRF in the control software or user interface app?

HyQual multiprobes provide a Sensor Response Factor (SRF) is a metric or figure of merit for the calibration. SRF is based on 100 as reference value; it shows the sensor's performance in relation to the standards used in development and production. SRF helps indicate if calibration was properly done.

Many competitor brands do not provide sensor response values; if you have a wrong or old standard and you falsely calibrate your instrument, you would not know it and the quality of your data collected after this calibration could be suspect.

Suppose that a typical Conductivity sensor reports 100 μA in a 1413 $\mu\text{S}/\text{cm}$ standard. If your particular Conductivity sensor reports 100 μA in that same calibration solution, then your SRF is 100 % (Some parameters such as pH have a more complex SRF calculation, but the effect is the same.). If your response is 80 μA , your SRF would be 80 %. When you click the "OK" button to accept a calibration, the HyQual probe automatically accepts your calibration if the SRF is between 60 % and 140 %. If the SRF falls outside that range, you will be cautioned to check your standard value, make sure the sensor is clean, make sure the reading has stabilized, etc. You can elect to accept any SRF. Each sensor calibration's Sensor Response Factor (SRF) is automatically logged into the Cal, recording details of that calibration.

What is a good SRF?

Generally, a SRF between 80 and 120 is good, and 60 to 140 is acceptable. If your SRF is outside these limits, check your standard value and the maintenance condition of your sensor.

Do I Have to Calibrate Temperature?

No, the Temperature sensor does not need calibration.

What is the Basic Calibration Procedure?

The HyQual probe never guesses parameter values, so you have to calibrate it from time to time by simply telling the instrument what it should read in a known calibration situation.

The general procedure is outlined, below:

1. Clean the sensor and perform any necessary sensor-specific maintenance.
2. Select a calibration standard whose value is close to the values you expect to see in the field.
3. Rinse sensors thoroughly (more than once may be required) with deionized (DI) water, especially if you have been using other calibration solutions. Vigorously shake the HyQual probe, so the DI can remove traces of old calibration solutions and cleaning agents. Repeat if necessary.
4. Rinse the sensors twice with a small quantity of your calibration standard. Discard the used calibration standard because it is probably contaminated with DI water.
5. Immerse the sensor in the calibration standard. This is usually accomplished by securing your HyQual probe with the sensors pointing up, screwing the cup onto the HyQual probe, and filling the cup with your calibration standard. Make sure the standard entirely covers the sensor, and that it also covers the thermistor for parameters that are temperature-compensated.
6. Watch the parameter readings until they have stabilized. Select the parameter to be calibrated. From the Probe menu option, choose "Calibrate" in the HyQual Control software and then click on the parameter you wish to calibrate. (Click "Calibrate" in the User Interface App and then choose the parameter.) For Parameters that have two calibration points, specify which you wish to calibrate (usually High or Low). Enter the calibration value and click "OK". The HyQual will report the resulting Sensor Response Factor (SRF). Then click "OK" to accept the calibration or "Quit" to leave the sensor uncalibrated. Please see the user manual available on the [HyQual webpage](#), topic Sensor warm up.
7. Each sensor calibration's Sensor Response Factor (SRF) is automatically logged into the Cal. Record with the details of that calibration.

For more information about calibration, see slides 29 - 42 in the online [Technical Training Guide](#).

Can I Use Cal. Solutions More Than Once?

If your quality control (QC) protocol requires fresh Cal. solutions for every calibration, then you may discard the once-used solutions. If your QC protocol does not require, then your sensitivity cost and accuracy will determine whether you can re-use Cal. solutions. For instance, if you want your field conductivity readings to be within 1 % of reading, then fresh conductivity Cal. solution, which is not very expensive, should be used every calibration. If you are not keen on turbidity accuracy, you can probably reuse your turbidity Cal. solution once or twice because it has a higher cost than other solutions.

What standard should I use to calibrate conductivity (SC)? What type?

For any parameter, use a calibration standard that is near the highest reading you anticipate in the field. For instance, if your lake usually runs about 1000 $\mu\text{S}/\text{cm}$, then calibrate with the readily available 1413 $\mu\text{S}/\text{cm}$ KCl standard.

Note: Some sensors (not SC) have two calibration points; the second point should be set at a convenient low point, usually zero.

What is the difference between calibrating % sat or milligrams per liter for dissolved oxygen (DO)?

Percent saturation (% sat) indicates the amount of oxygen compared to the amount if the water were saturated with oxygen. Milligrams per liter (mg/l) indicates the amount of oxygen dissolved in one liter of water. For instance, if your HyQual probe read 6.0 mg/l and the saturation tables indicate that at that particular temperature, salinity and barometric pressure, the saturation value was 8.0 mg/l, then your % sat would be $6/8 = 75\%$. Use either measurement or both, but % sat is helpful during DO calibration because it should always be 100 %.

What is the different between the Amco Clear turbidity standard and StablCal?

Amco Clear is made of polymer beads; StablCal is a formazin compound. Most people want turbidity measurements referenced to formazin, so use formazin or StablCal for calibrations. The polymer beads are cheaper and more stable, BUT you must know the equivalent formazin value for any polymer bead standard. You cannot rely on the polymer-bead label; you must check it with your own instrument after the probe has been calibrated with formazin or StablCal.

10.1.8 Integration

For the following options available: depth sensor, SDI-12 and MODBUS output, external lithium battery, Bluetooth® wireless technology battery pack and/or addition of sensors, can they all be used together or may certain configurations conflict with the use of the others?

No; all those products can be used on the same multiprobe.

Does HyQual integrate to KISTERS data loggers?

HyQual probes integrate with the family of data loggers iRIS by KISTERS.

10.1.9 Deployment and Applications

For questions related to power supply please refer to the [Power supply](#) ³²¹ chapter.

How do I deploy my probe when there is no bail hook? Is it OK to hang the instrument by the cable? How much weight will the cable hold?

When properly attached, the HyQual Underwater Cable can support well over 50 lbs (22.7 kg) without requiring a Bail Kit. You can hang the HyQual probe by the Underwater Cable if the load is not likely to exceed 50 lbs (22.7 kg). Please be aware that the flow velocity may influence the load.

What anti-fouling products do you offer?

We offer copper replacements for copper gauze anti fouling kits.

Why is it important to check water temperature in a range of temperatures in the lab before deployment? How often?

It's not that important. The HyQual design has been tested many times to ensure it accounts for water temperature everywhere necessary, such as when calculating DO saturation.

10.1.10 Accessories

What underwater cable lengths are available, and are they standard or optional?

We offer 5 m, 10 m, 20 m, 30 m, 40 m and 50 m cable lengths and they all are standard in the different package choices.

What cleaning accessories are available for the HyQual probe?

HyQual 300T has a standard wiper for the turbidity sensor.

Do you have special protection or a case for unattended monitoring?

Yes, we offer a protection pipe kit that fits all HyQual models and protects them from external conditions such as stones or sticks. You can also add a pipe on the system with a longer longitude to locate it in more difficult measuring points.

10.1.11 Measurement variables

What is the maximum number of parameters HyQual 200 and HyQual 300T can measure at the same time?

There is a difference between parameters and sensors in that one sensor can provide several parameters. For instance, the conductivity sensor provides the parameters conductivity, specific conductivity, total dissolved solids, salinity, and resistivity. 200 has maximum capacity of six sensors: temp, DO, SC, pH, ORP, and depth.

What is the maximum number of sensors HyQual 300T can have at the same time?

HyQual 300T has a maximum of seven sensors: temp, DO, SC, pH, ORP, depth, and turbidity.

How do HyQual probes measure depth?

Choice 1 Standard non-vented capacity + optional depth sensor:

When located at the riverbed when taking measurements, the probe measures the Absolute Pressure = Barometric Pressure (atmospheric pressure) + Water Pressure (water column pressure), and then converts that pressure to water depth.

Choice 2 Optional vented capacity + optional depth sensor:

When vented capacity is used, the calculation of depth is more precise as it does not depend on theoretical values, variation values resulting from the spot of measurement, climate conditions in the specific moment of measurement or others which affect the calculation of Barometric Pressure with a non-vented capacity. In this case, the value of depth is obtained by correcting the Absolute Pressure for Barometric Pressure, which the instrument does automatically.

Note: Vented capacity is optional, it requires to add an optional depth sensor, optional vented depth capacity, and an optional vented cable. Additionally, this capacity is incorporated in the probe so you will add it when purchasing the probe. If you happen to have a probe and need to incorporate this capacity, you will have to send the probe back to us at your own expense.

How do HyQual probes measure Barometric Pressure?

Barometric pressure is calculated with the use of the depth sensor therefore, you will need to add an optional depth sensor to any of your probes HyQual 200, and HyQual 300T.

When Absolute Pressure method is used (non-vented capacity) there are three ways of obtaining the value of Barometric Pressure:


- With the use of a theoretical Barometric Pressure
- With the use of the depth sensor, by taking the probe out of the water and placing it at the water surface so that the probe only measures the Barometric Pressure
- With a barometer (any brand)

Note: The barometric pressure value is needed for the calibration of the DO sensor.

Are Salinity and Total Dissolved Solids (TDS) calculated values? If so, are they calculated from conductivity and temperature?

Salinity and TDS are calculated from conductivity and temperature.

How do I know which sensor is which?



Do the probes have standard both sensors, pH and ORP ?

The oxidation-reduction potential (ORP) sensor is standard; it is not an option as in most other probes. The inclusion of an ORP sensor is uncommon for an instrument in this price range; normally ORP is a high-margin add-on.

Most competitor brands offer one or the other sensor; both pH and ORP sensors are not standard. In HyQual probes, both pH and ORP are standard.

Why is it important to check the Conductivity (SC) reading in air? What should it be?

A well-dried SC sensor should produce a zero reading in air. This indicates that a one-point calibration is adequate.

Can I see the slope calculation for pH?

Yes, you can. Look at the millivolts (mV) readings in your calibration log. There is little to no need to do this task with a HyQual probe because the reference electrode seldom needs replacement, i.e. you need only monitor pH slope for devices by manufacturers whose reference electrodes always move toward failure and require replacement of the pH/reference sensor.

Will my HyQual probe also report Total Dissolved Solids (TDS) and/or Salinity?

Yes.

Can I customize the HyQual probe with different configurations of sensors?

Yes, you can. The standard packages currently offered include all the sensors but you can customize your probe by reducing or adding these sensors: Add depth sensor, remove Dissolved Oxygen sensor, remove pH/ORP sensors, remove Specific Conductivity sensor.

Why can a turbidity measurement read negative?

The Turbidity reading has been designed to read negative, in order to indicate a problem with the Turbidity Low calibration. For instance, if you calibrate at zero with water that is actually 5 NTU, then any sample less than 5 NTU will read negative. Recalibration would be needed. Some manufacturers “clip” Turbidity readings at zero to avoid this issue; the practice is misleading and fails to record good information.

10.1.12 Materials**From what materials are the probes made?**

The probes are made from 303 and 316 stainless steel, polyacetal (Delrin), PVC, Teflon, ABS, titanium, Viton, neoprene, silicone, and glass.

Are all the battery types (Bluetooth® and external (no Bluetooth)) lithium?

Yes.

10.1.13 Differences and common points**What is common among the 2 robes?**

- They all offer an industry leading 3-year warranty.
- They all come with the following standard sensors: Temperature sensor, Dissolved Oxygen, Specific conductivity and pH/ORP.
- Depth sensor is optional.
- Vented capacity is optional.
- They all have an internal memory allowing months of datalogging.
- The maintenance kit and carrying case are all standard.
- Interfaces: RS-232 is standard. SDI-12 and MODBUS, Bluetooth® wireless technology are optional.
- Options: Depth (level) sensor, Bluetooth® wireless technology battery pack, calibration solutions, copper anti-fouling kit, USB adapter (connect DB9 to USB), integrated SDI-12 and MODBUS output, SDI-12 adapter cable, MODBUS adapter cable, Android display.

What are the differences among HyQual 200 and HyQual 300T?

- HyQual 200 (0.82 kg, 50 mm × 47.8 mm) and HyQual 300T (1.63 kg, 75 mm × 47.8 mm) have different diameter, mass and price.
- HyQual 300T by default has a turbidity sensor and a wiper. Wiper and turbidity sensor are not included nor an option on HyQual 200.
- HyQual 300T has an optional Rechargeable EBP External Battery Pack (for unattended /stand-alone monitoring). You can also use it for HyQual 200 but the diameter of the battery is larger than the diameter of the probe, it will look top headed with the battery works properly.
- HyQual 200 and HyQual 300 hold up to 6 sensors at the same time: Temperature, Dissolved Oxygen, Specific conductivity, pH, ORP, Depth.

- HyQual 300T up to 7 sensors at the same time – the same 6 plus turbidity.

10.1.14 Other topics


















Can HyQual probes be used for seawater applications?

Yes; they can operate in a temperature range from -5 °C (23 °F) to +45 °C (113 °F) and submersed down to a depth of 50 m (164 ft).

What do the LEDs mean?

Please see the first chapter of the user manual available in Downloads on the [HyQual webpage](#).

Contact Data

Europe	KISTERS Europe	 +49 2408 9385 0
		 hydromet.sales@kisters.eu
		 www.kisters.eu
Australia	KISTERS Australia	 +612 9601 2022
		 sales@kisters.com.au
		 www.kisters.com.au
New Zealand	KISTERS New Zealand	 +64 7 857 0810
		 sales@kisters.co.nz
		 www.kisters.co.nz
Latin America	KISTERS Latin America	 +57 350 575 4079
		 sales@kisters-latam.com
		 www.kisters-latam.com
North America	KISTERS North America	 +1 561 459 4876
		 kna@kisters.net
		 www.kisters.net
Spain	KISTERS Ibérica	 info@kisters.es
		 www.kisters.es

